

Goodwe Inverter Monitoring

It is possible to monitor your Goodwe Inverter in multiple ways, either via the web, your smart phone or tablet with a single universal username and password.

As part of your solar installation M Solar Power will configure your inverter Wi-Fi, web portal and assist with the installation of the monitoring apps for your iPhone, iPad, Android smartphone and or tablet.

Your Goodwe inverter ships standard with Wi-Fi which connects to your home or business's Wi-Fi network. This connection permanently required to log your date, if the inverter location is out of range additional wifi repeaters may be required.

If you make a change to your ADSL network or Wi-Fi position or settings the inverters connection to the internet will be lost. This will require the new password and or wifi settings to be inputted to the inverter. Instructions on how to reconnect your inverter are provided or a call out from our technician is available if needed to assist you further.

Goodwe Web Portal

Solar plant monitoring via the web is available at <http://www.goodwe-power.com/> with the username and password provided.

For lost password please visit <http://www.goodwe-power.com/User/ForgetPwd>.

The screenshot shows the Goodwe web portal interface. At the top, there is a navigation bar with the Goodwe logo (a red square with a white 'G' inside) and the text "GOODWE your solar engine". To the right of the logo are links for "Chinese", "English", "Service Center", and "User Manual". Below the navigation bar is a large banner image showing several colorful (red, white, blue, yellow) Goodwe inverters mounted on a blue solar panel array under a bright sun.

Below the banner, there is a dashboard with several widgets:

- Overview**: A table with the following data:

Stations	12676
ETotal (GWh)	56.60
Total Avoid (KT)	25.75
- Shared Stations**: A button with a right-pointing arrow.
- Demo**: A button with a right-pointing arrow.
- Login/Registration**: A form with a "demo" username, a password field, a "Remember ..." checkbox, and buttons for "Login", "Register", and "Forgot your password? Click here".

Below the dashboard, there is a grey bar with the text "Where the sun shines, there is GoodWe!". Underneath this bar are two buttons for mobile apps: "GoodWe EzViewer" with an iPhone icon and "GoodWe EzViewer" with an Android icon.

At the bottom of the page, there is a black footer bar with the text "Copyright © 2012 www.goodwe.com.cn All Rights Reserved." and the Goodwe logo.



Goodwe Software

EzViewer enables you to **remotely view** real-time and historical information of your power stations via your smartphone or tablet when either connected to the internet via Wi-Fi or 3G.

Log on using your universal username and password.

EZViewer for iPhone / iPad

Search for 'ezviewer' in the Apple App store to install on your iPhone and or iPad or follow the link below.

<https://itunes.apple.com/cn/app/goodweezviewerhd/id833377595?mt=8>

EZViewer Andriod

Search for 'ezviewer' in the Google play store to install on your Android Smartphone or table or download from the link below.

<https://play.google.com/store/apps/details?id=com.goodweforphone&hl=en>

EZManager Android (for local Hybrid Inverter Monitoring)



EzManage enables real-time monitoring of your hybrid inverter while connected directly to your internal Wi-Fi network, please use EZManage for remote viewing.

To download for 'ezviewer' in the Google play or Apple App Store to install Smartphone or table or download from the link below.

Android - <https://play.google.com/store/apps/details?id=com.goodwe.EzManage&hl=en>

Apple - <https://itunes.apple.com/us/app/ezmanage/id918410068?mt=8>

The default 'Solar Wi-Fi' password is '12345678' unless changed typically to match your own Wi-Fi password.